

# KISS MY BASS™

2 or More Players  
Ages 10 to Adult

## Rules


**Contents:**  
Bass, Rules

### Play:

- Turn the Bass on by touching his fin.
- Listen to his commands and do what he says, and then pass to the next player.
- If you're too slow or mess up, he'll bust your chops and he'll fart! The person holding him when he does is the LOSER!
- Now play again. Or just take your bass everywhere you go for a laugh.




### Touch Points:



## BATTERY INSTALLATION

- Alkaline batteries are recommended for best performance. Remove the battery cover using a screwdriver and insert two AA batteries, as shown. Then screw the battery cover back on.
- Note: The bass will not function if the batteries are inserted incorrectly.



## BATTERY INFO

### BATTERY SAFETY INFORMATION

In exceptional circumstances, batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- Adult supervision is recommended when changing batteries.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Dispose of batteries safely.
- Batteries may explode or leak if disposed of in a fire.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**PlayMonster**



We wanna hear about all the fun you had!

Get in touch at: Customer Service, 1400 E. Inman Pkwy.,  
Beloit, WI 53511  
playmonster@playmonster.com • 1-800-524-4263.  
For more fun, visit [playmonster.com](http://playmonster.com)

Copyright © 2019 PlayMonster LLC, 1400 E. Inman Pkwy., Beloit, WI 53511 USA.  
Made in China. All rights reserved. **Kiss My Bass** and **Pucker Up Buttercup** are trademarks of PlayMonster LLC.

Keep these instructions for future reference as they contain important information.  
Do not place this product in the water.